



Installation Guide

Alarm -	RJ45-1	BEEP
Alarm +	RJ45-2	GLED
NC	RJ45-3	RLED
COM	RJ45-6	WD1
NO		WD0
Button	WD0	GND
GND	WD1	+12V
Sensor	GND	
Bell +	232RX	
Bell -	232TX	
	GND	
GND	485 A	
+12V	485 B	



ECO2300D



TIMEPRINT
www.ecotimeprint.com