

Wiring Installation Guide

ALM -	RJ45-1	BEEP
ALM +	RJ45-2	GLED
NC	RJ45-3	RLED
COM	RJ45-6	INWD0
NO		INWD1
BUT	WD0	GND
GND	WD1	+12V
SEN	GND	
BEL +	RXD	
BEL -	TXD	
	GND	
	485+	
	485-	




VRS200



VRS200S

12V	12V
GND	GND
D0	D1
D1	D1
LED	RLED
BEEP	GLED
26/34	BEEP



TIMEPRINT

www.ecotimeprint.com